







Glue Lock Compatibility and Variation Guide

In 15% of cases the customer will not have the standard thumb turn lock. Often the Glue Lock is still compatible with another lock type with additional components they can get from the Compatibility Kit or Glue Customer Support. Use this guide to help you identify different locks and locks which are not compatible.

Example	Lock Type	Compatibility	Additional Action Required
	<p>Standard Scandinavian Thumbturn (85%+ of locks)</p>	<p>Compatible</p> <p>No additional components required</p>	<p>None, follow existing instructions exactly as stated to complete the installation</p>
	<p>Key cylinder lock on interior of door (may also be thumb turn mounted on a cylinder)</p>	<p>Compatible</p> <p>D-plate & 2x screws required, available in separate Compatibility Kit product</p>	<ol style="list-style-type: none"> 1. Remove key cylinder ring using hex key/screwdriver 2. Remove cylinder, then insert new tail piece from Compatibility Kit into lock and screw in the D-plate 3. Mount the Glue Lock on the newly inserted tail piece <p>(Follow <i>CompatibilityKit_dplate</i> instructions for more details)</p>

Example	Lock Type	Compatibility	Additional Action Required
	<p>Key cylinder lock with thumb turn and täckplatta</p>	<p>Compatible</p> <p>D-plate & 2x screws + new täckplatta available in separate Compatibility Kit product</p>	<ol style="list-style-type: none"> 1. Remove key cylinder ring using hex key/screwdriver 2. Remove cylinder and handle, then remove existing täckplatta 3. Fit new tail piece and D-plate to cylinder 4. Place new täckplatta onto the door and screw in the handle again to hold it in place 5. Mount the Glue Lock on the newly inserted tail piece <p>(Follow <i>CompatibilityKit_täckplatta</i> instructions for more details)</p>
			<p>Mortise locks and latches shown in these pictures are Not Compatible with the Glue Lock</p>